



BENCH ELECTRIC ELECTRODE TIP DRESSER



Click-on Link to view
Operational Video



<https://bit.ly/bench-tipdresser>

Dressing of Caps / Electrodes:

- Insert used cap or electrode on Taper Shank or Taper Socket.
- Push Lever to insert cap tip into Electric Dresser.
- Electric Motor will start automatically.
- Cap / Electrode will be dressed in 2/3 seconds.
- Push lever to full right, electrode will be ejected automatically and fall in blue bin.
- Cutters can be supplied to suit the shape of electrodes.
- Cutters can be replaced / changed in 30 seconds.

